

CITY OF ROCKWALL

OPERATING PROCEDURES FOR INSTALLING CONSTRUCTION METERS ON FIRE HYDRANTS

1. You must have the proper fire hydrant wrench to operate the hydrant.
2. Secure the caps that are not being used.
3. Make sure the meter flange has a gasket to eliminate any leaks.
4. Turn hydrant on fully.
5. If there are any leaks at the base of the hydrant or at the caps notify the City of Rockwall Service Center at 972-771-7730.
6. Upon completion of the work day, turn the hydrant off slowly until snug. Do not over tighten the operating nut.

